

FLOW EVO

Infrared gas sensor SO₂ // Sulfur Dioxide // 2000 ppm smartGAS item number: F3-432205-05000















- Pre calibrated
- Compact design
- 3/5 mm gas line connectors
- 3.3 6 V DC supply voltage
- Modbus ASCII or RTU
- Status indication by LED
- Low drift

Non Dispersive Infrared (NDIR) gas sensor for process control and gas analysing using dual wavelength technology. Designed for different applications such as emission monitoring or process control in a wide range of gas measurement systems.

The FLOW^{EVO} sensor can easily be integrated into OEM systems, where long term stability, repeatability and reliable performance are required. It can be used in the food industry, for stack gas monitoring in incineration plants but also in the field of environmental analysis. High-precision NDIR technology requires little maintenance compared to conventional chemical sensors and its small detection thresholds and long life expectancy qualify our NDIR sensors for numerous tasks in countless areas of scientific research.

Modbus ASCII or RTU data communication offer a variety of options to connect the ${\sf FLOW}^{\sf EVO}$ sensor to a controller.

APPLICATION EXAMPLES

EMISSION MONITORING
PROCESS CONTROL
LAB ANALYSING
RESEARCH
ENVIRONMENTAL ANALYSING
FOOD INDUSTRY





Infrared gas sensor SO₂ // Sulfur Dioxide // 2000 ppm smartGAS item number: F3-432205-05000

General features

Measurement principle: Non Dispersive Infra-Red (NDIR), dual wavelength

Measurement range: 0 .. 2000 ppm Full Scale (FS)

Gas supply: by flow (nearly atmospheric pressure)

Flow rate: 0.1 .. 1.0 l / min

Dimensions: 153 mm x 30 mm x 36 mm (L x W x H)

Warm-up time: < 2 minutes (start up time)

< 30 minutes (full specification)

Measuring response*

Response time (t_{90}) : Appr. 12 s @ 0.7 l / min

Digital resolution (@ zero): 1 ppm

Detection limit (3 σ): \leq 12 ppm

Repeatability: \leq \pm 15 ppm

Linearity error (straight line deviation): \leq \pm 20 ppm

Long term stability (span): $\leq \pm 40$ ppm over 1000 h period Long term stability (zero): $\leq \pm 40$ ppm over 1000 h period

Influence of T, P, flow rate, other*

Temp. dependence (zero): $\leq \pm 2$ ppm per °C Temp. dependence (span): $\leq \pm 4$ ppm per °C

Pressure dependence: + 0.121 % of measurement value / hPa

Flow rate dependence: $\leq \pm 3$ ppm per 0.1 l/min

Cross sensitivity (zero) other gases: $\leq \pm 10 \text{ ppm } @ 10\% \text{ CO}_2 \text{ in dry air}$

Electrical inputs and outputs

Supply voltage: 3.3 V .. 6.0 V DC

Supply current (peak): < 400 mA @ 3.3 V, < 240 mA @ 5.0 V

Inrush current: < 600 mA
Average power consumption: < 800 mW

Digital output signal: Modbus ASCII / RTU via UART, autobaud, autoframe

Calibration: zero and span by SW

Climatic conditions

Operating temperature: $0..+50 \,^{\circ}\text{C}$ Storage temperature: $-20..+60 \,^{\circ}\text{C}$ Air pressure: $800..1150 \, \text{hPa}$

Ambient humidity: 0 .. 95 % relative humidity (not condensing)

* Typical values related to 1013 hPa, Ta=22 °C, flow = 0.7 l / min for dry (not condensing) and clean sample gas. Stated values exclude calibration gas tolerance.

All rights reserved. Any logos and/or product names are trademarks of smartGAS. The reproduction, transfer, distribution or storage of information contained in this brochure in any form without the prior written consent of smartGAS is strictly prohibited. All specifications – technical included – are subject to change without notice. Depending on the application, the target gas and the measurement range the technical data may differ. No liability is accepted for any consequential losses, injury or damage resulting from the use of this document or from any omissions or errors herein. The data is given for guidance only. It does not constitute a specification or an offer for sale.

For more information, please visit www.smartgas.eu or contact us at sales@smartgas.eu

Please consult smartGAS sales for parts specified with other temperature and measurement ranges.

At first initiation and depending on application and ambient conditions recalibration is recommended. Recurring cycles of recalibration are recommended.