

FLOW EVO

Infrared gas sensor CO // Carbon monoxide // 2000 ppm smartGAS item number: F3-222205-05000

















- Pre calibrated
- Compact design
- 3/5 mm gas line connectors
- 3.3 6 V DC supply voltage
- Modbus ASCII or RTU
- Status indication by LED
- Low drift

Non Dispersive Infrared (NDIR) gas sensor for process control and gas analysing using dual wavelength technology. Designed for process control, lab analysing and environmental monitoring in a wide range of gas measurement systems.

The FLOW^{EVO} CO sensor can easily be integrated into OEM systems, where long term stability, repeatability and reliable performance are required. Based on robust and precise NDIR technology our CO sensors offer enduring solutions in the area of controlled combustion and process control. Furthermore, they can be used in environmental analysis and various other fields of scientific research where low signal drift and high selectivity are crucial for exact measurements and subsequent processing.

Modbus ASCII or RTU data communication offer a variety of options to connect the FLOW^{EVO} sensor to a controller.

APPLICATION EXAMPLE

EMISSION MONITORING
ENVIRONMENTAL MONITORING
PROCESS CONTROL
RESEARCH
GAS ANALYSING
BIO GAS



FLOW^{EVO}

Infrared gas sensor CO // Carbon monoxide // 2000 ppm smartGAS item number: F3-222205-05000

General features

Measurement principle: Non Dispersive Infra-Red (NDIR), dual wavelength

Measurement range: 0..2000 ppm Full Scale (FS)

Gas supply: by flow (nearly atmospheric pressure)

Flow rate: 0.1 .. 1.0 l / min

Dimensions: 153 mm x 30 mm x 36 mm (L x W x H)

Warm-up time: < 2 minutes (start up time)

< 30 minutes (full specification)

Measuring response*

Response time (t_{90}) : Appr. 12 s @ 0.7 l / min

Digital resolution (@ zero): 1 ppm Detection limit (3 σ): \leq 20 ppm Repeatability: \leq \pm 20 ppm Linearity error (straight line deviation): \leq \pm 30 ppm

Long term stability (span): $\leq \pm 50$ ppm over 1000 h period Long term stability (zero): $\leq \pm 50$ ppm over 1000 h period

Influence of T, P, flow rate, other*

Temp. dependence (zero): $\leq \pm 3$ ppm per °C Temp. dependence (span): $\leq \pm 6$ ppm per °C

Pressure dependence: + 0.134 % of measurement value / hPa

Flow rate dependence: $\leq \pm 6$ ppm per 0.1 l/min

Cross sensitivity (zero) other gases: $\leq \pm 700$ ppm @10 % CO2 in dry air

Gas dew point requirement: < + 5 °C

Electrical inputs and outputs

Supply voltage: 3.3 V .. 6.0 V DC

Supply current (peak): < 400 mA @ 3.3 V, < 240 mA @ 5.0 V

Inrush current: < 600 mA
Average power consumption: < 800 mW

Digital output signal: Modbus ASCII / RTU via UART, autobaud, autoframe

Calibration: zero and span by SW

Climatic conditions

Operating temperature: $0 ... + 50 \,^{\circ}\text{C}$ Storage temperature: $-20 ... + 60 \,^{\circ}\text{C}$ Air pressure: $800 ... 1150 \,^{\circ}\text{hPa}$

Ambient humidity: 0 .. 95 % relative humidity (not condensing)

* Typical values related to 1013 hPa, Ta=22 °C, flow = 0.7 l / min for dry (not condensing) and clean sample gas. Stated values exclude calibration gas tolerance.

All rights reserved. Any logos and/or product names are trademarks of smartGAS. The reproduction, transfer, distribution or storage of information contained in this brochure in any form without the prior written consent of smartGAS is strictly prohibited. All specifications – technical included – are subject to change without notice. Depending on the application, the target gas and the measurement range the technical data may differ. No liability is accepted for any consequential losses, injury or damage resulting from the use of this document or from any omissions or errors herein. The data is given for guidance only. It does not constitute a specification or an offer for sale.

For more information, please visit <u>www.smartgas.eu</u> or contact us at <u>sales@smartgas.eu</u>

Please consult smartGAS sales for parts specified with other temperature and measurement ranges. At first initiation and depending on application and ambient conditions recalibration is recommended. Recurring cycles of recalibration are recommended.